

Name : LPC\_PGM2 REV: 1.2.1  
 Date : 24-02-2005

Count 4 falling edges on RST (RTS input)  
 At count is 4 release LPC after a short delay and enable reload of counter  
 at the next clock edge

